



**Auto Care USA**  
a division of Northwest Equipment Manufacturing, Inc.  
122 East Reserve Dr. • Kalispell, MT 59901 USA  
• Office: 406-755-0805 • Fax: 406-755-0813  
nwEquipmentSales.com



Reach us at: 877-349-2327 or 406-755-0805



### Instructions for using Trailer Kingpin Extension

1. Adjust **base tube** into **adjustment tube** to approximate height of kingpin on trailer using adjustment holes.
2. Depress **cone** and **centering rod** and place under kingpin of trailer.
3. Adjust **bubble assembly** to approximate height of the center of the tandem wheel hub.
4. Point the **tape hook** directly down a line through the center of the axles. Tighten thumb screw.
5. Straighten **kingpin extension** by centering **bubble** in **bubble level**.
6. Place loop of tape over **tape hook** and proceed with measurements.